

Video

Digital Cameras

Applied Video Systems, Inc.

5816-D Shakespeare Road

Columbia SC 29223

803-735-1120, 800-325-2281

Fax: 803-735-1121

sales@appliedvideosystems.com

www.appliedvideosystems.com

Canon PowerShot Digital Cameras

Contract # 4400013015

Effective 10-18-17

See Tabs at bottom of page

ITEM CODE NO.	PRODUCT DESCRIPTION	UPC CODE		SUGG. LIST PRICE	Contract
POWERSHOT G SERIES					
NEW	2208C001	PowerShot G1 X Mark III Kit (Black)	013803 295597	PowerShot G1 X Mark III, Battery Pack NB-13L, Battery Charger CB-2LH, Neck Strap NS-DC12, Strap Adapters	\$ 1,700.00 \$ 1,299.00
	9167B001	PowerShot G1 X Mark II Kit (Black)	013803 240047	PowerShot G1 X Mark II, Battery Pack NB-12L, Battery Charger CB-2LG, Neck Strap NS-DC11	\$ 899.99 \$ 799.99
	0106C001	PowerShot G3 X Kit (Black)	013803 254754	PowerShot G3 X, Battery Pack NB-10L, Battery Charger CB-2LC, Lens Cap (with Strap), Neck Strap NS-DC11	\$ 1,099.99 \$ 999.99
	0510C001	PowerShot G5 X Kit (Black)	013803 266986	PowerShot G5 X, Battery Pack NB-13L, Battery Charger CB-2LH, Neck Strap NS-DC12, Strap Adapters	\$ 899.99 \$ 799.99
	1066C001	PowerShot G7 X Mark II Kit (Black)	013803 269321	PowerShot G7 X Mark II, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 799.99 \$ 699.99
	1066C029	PowerShot G7 X Mark II Video Creator Kit (Black)	660685 163270	PowerShot G7 X Mark II, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12, Manfrotto™ PIXI Mini Tripod (Black), 32GB Class 10 SDHC Memory Card, Extra Battery Pack NB-13L	\$ 849.99 \$ 749.99
	1718C001	PowerShot G9 X Mark II (Silver)	013803 284942	PowerShot G9 X Mark II, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 629.99 \$ 529.99
	1717C001	PowerShot G9 X Mark II (Black)	013803 284928	PowerShot G9 X Mark II, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 629.99 \$ 529.99
	0924C001	PowerShot G9 X Kit (Silver)	013803 266450	PowerShot G9 X, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 629.99 \$ 529.99
	0511C001	PowerShot G9 X Kit (Black)	013803 266443	PowerShot G9 X, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 629.99 \$ 529.99
POWERSHOT SX SERIES					
	9543B001	PowerShot SX60 HS Kit (Black)	013803 244908	PowerShot SX60 HS, Battery Pack NB-10L, Battery Charger CB-2LC, Lens Cap (with Strap), Neck Strap NS-DC11	\$ 649.99 \$ 549.99
	1067C001	PowerShot SX540 HS Kit (Black)	013803 269338	PowerShot SX540 HS, Battery Pack NB-6LH, Battery Charger CB-2LY, Lens Cap (with Strap), Neck Strap NS-DC11	\$ 499.99 \$ 399.99
	9779B001	PowerShot SX530 HS Kit (Black)	013803 244793	PowerShot SX530 HS, Battery Pack NB-6LH, Battery Charger CB-2LY, Lens Cap (with Strap), Neck Strap NS-DC11	\$ 479.99 \$ 379.99
NEW	1791C001	PowerShot SX730 HS Kit (Black)	013803 286090	PowerShot SX730 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Wrap WS-800	\$ 499.99 \$ 399.99
NEW	1792C001	PowerShot SX730 HS Kit (Silver)	013803 286113	PowerShot SX730 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Wrap WS-801	\$ 499.99 \$ 399.99
	1070C001	PowerShot SX720 HS Kit (Black)	013803 269369	PowerShot SX720 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 479.99 \$ 379.99
	0109C001	PowerShot SX710 HS Kit (Black)	013803 252552	PowerShot SX710 HS, Battery Pack NB-6LH, Battery Charger CB-2LY, Wrist Strap WS-800	\$ 449.99 \$ 349.99
	1073C001	PowerShot SX620 HS Kit (Red)	013803 269574	PowerShot SX620 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 379.99 \$ 279.99
	1072C001	PowerShot SX620 HS Kit (Black)	013803 269567	PowerShot SX620 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 379.99 \$ 279.99
	1074C001	PowerShot SX620 HS Kit (Silver)	013803 269581	PowerShot SX620 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 379.99 \$ 279.99
	1068C001	PowerShot SX420 IS Kit (Black)	013803 269345	PowerShot SX420 IS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-DC12	\$ 399.99 \$ 299.99
	1069C001	PowerShot SX420 IS Kit (Red)	013803 269352	PowerShot SX420 IS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-DC12	\$ 399.99 \$ 299.99
POWERSHOT D SERIES					
	9337B001	PowerShot D30 Kit (Blue)	013803 240795	PowerShot D30, Battery Pack NB-6LH, Battery Charger CB-2LY, Wrist Strap WS-DC8	\$ 429.99 \$ 329.99
POWERSHOT N SERIES					
	9169B001	PowerShot N100 Kit (White)	013803 242485	PowerShot N100, Battery Pack NB-12L, Battery Charger CB-2LG, Wrist Strap WS-DC12	\$ 449.99 \$ 349.99
	9168B001	PowerShot N100 Kit (Black)	013803 242492	PowerShot N100, Battery Pack NB-12L, Battery Charger CB-2LG, Wrist Strap WS-DC12	\$ 449.99 \$ 349.99
	9770B001	PowerShot N2 Kit (White)	013803 244922	PowerShot N2, Battery Pack NB-9L, Compact Power Adapter CA-DC30, USB Interface Cable IFC-400PCU, Wrist Strap WS-800	\$ 399.99 \$ 299.99
	9547B001	PowerShot N2 Kit (Black)	013803 244915	PowerShot N2, Battery Pack NB-9L, Compact Power Adapter CA-DC30, USB Interface Cable IFC-400PCU, Wrist Strap WS-800	\$ 399.99 \$ 299.99
POWERSHOT DIGITAL ELPH SERIES					
	1081C001	PowerShot ELPH 360 HS Kit (Purple)	013803 269611	PowerShot ELPH 360 HS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 309.99 \$ 209.99
	1078C001	PowerShot ELPH 360 HS Kit (Silver)	013803 269604	PowerShot ELPH 360 HS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 309.99 \$ 209.99
	1075C001	PowerShot ELPH 360 HS Kit (Black)	013803 269598	PowerShot ELPH 360 HS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 309.99 \$ 209.99
	0154C001	PowerShot ELPH 350 HS Kit (Black)	013803 252514	PowerShot ELPH 350 HS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 309.99 \$ 209.99
	0158C001	PowerShot ELPH 350 HS Kit (Silver)	013803 252521	PowerShot ELPH 350 HS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 309.99 \$ 209.99
	1090C001	PowerShot ELPH 190 IS Kit (Blue)	013803 270006	PowerShot ELPH 190 IS, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 259.99 \$ 159.99
	1084C001	PowerShot ELPH 190 IS Kit (Black)	013803 269512	PowerShot ELPH 190 IS, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 259.99 \$ 159.99
	1087C001	PowerShot ELPH 190 IS Kit (Red)	013803 269529	PowerShot ELPH 190 IS, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 259.99 \$ 159.99
	0130C001	PowerShot ELPH 170 IS Kit (Blue)	013803 252743	PowerShot ELPH 170 IS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 249.99 \$ 149.99
	0114C001	PowerShot ELPH 170 IS Kit (Black)	013803 252217	PowerShot ELPH 170 IS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 249.99 \$ 149.99
	0127C001	PowerShot ELPH 170 IS Kit (Silver)	013803 252750	PowerShot ELPH 170 IS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 249.99 \$ 149.99

1093C001	PowerShot ELPH 180 Kit (Silver)	013803 269536	PowerShot ELPH 180, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 219.99	\$ 119.99
1096C001	PowerShot ELPH 180 Kit (Red)	013803 269543	PowerShot ELPH 180, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 219.99	\$ 119.99
0137C001	PowerShot ELPH 160 Kit (Silver)	013803 252897	PowerShot ELPH 160, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 219.99	\$ 119.99
0134C001	PowerShot ELPH 160 Kit (Black)	013803 252675	PowerShot ELPH 160, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 219.99	\$ 119.99
0143C001	PowerShot ELPH 160 Kit (Red)	013803 252910	PowerShot ELPH 160, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 219.99	\$ 119.99
0140C001	PowerShot ELPH 160 Kit (White)	013803 252903	PowerShot ELPH 160, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 219.99	\$ 119.99
CONNECT STATION					
9899B002 #	Connect Station CS100	013803 253740	#####	\$ 480.00	\$ 299.99
CASES					
NEW	3087C001 #	Deluxe Leather Case PSC-6300	660685 179608	PowerShot G1 X Mark III	\$ 99.99 \$ 89.99
	1023C001 #	Deluxe Leather Case PSC-6200	660685 141148	PowerShot G3 X	\$ 79.99 \$ 71.99
	9874B001 #	Deluxe Soft Case PSC-6100	660685 126367	PowerShot G1 X Mark II	\$ 69.99 \$ 62.99
	1709C001 #	Deluxe Leather Case PSC-5600	660685 152328	PowerShot G9 X Mark II, G9 X	\$ 39.99 \$ 35.99
	1625C001 #	Deluxe Leather Case PSC-5500	660685 151307	PowerShot G7 X Mark II, G7 X	\$ 59.99 \$ 53.99
	1282C001 #	Deluxe Leather Case PSC-5400	660685 146440	PowerShot G5 X	\$ 59.99 \$ 53.99
	0448C001 #	Deluxe Leather Case PSC-5300BK	660685 132702	PowerShot G7 X	\$ 59.99 \$ 53.99
	0235C001 #	Deluxe Soft Case PSC-4200	660685 131699	PowerShot SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, SX1 IS, SX540 HS, SX530 HS, SX520 HS	\$ 29.99 \$ 26.99
	8059B001 #	Deluxe Soft Case PSC-4050	660685 050259	PowerShot SX510 HS, SX500 IS, SX420 IS, SX410 IS, SX400 IS	\$ 24.99 \$ 22.49
	5021B001 #	Deluxe Soft Case PSC-3300	660685 026216	PowerShot G7 X, G9 X Mark II, G9 X, SX720 HS, SX710 HS, SX700 HS, SX620 HS, SX610 HS, SX600 HS, SX280 HS, SX260 HS, SX170 IS, SX160 IS, SX150 IS, SX130 IS, SX120 IS, SX110 IS, N100	\$ 19.99 \$ 17.99
	4854B001 #	Deluxe Leather Case PSC-3200	660685 023543	PowerShot S120, S110, S100, S95, S90, SX280 HS, SX260 HS, SX230 HS, SX210 IS, SX620 HS, SX610 HS, SX600 HS, ELPH 510 HS, ELPH 500 HS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 190 IS, ELPH 170 IS, ELPH 330 HS, SD4500 IS, A4000 IS	\$ 24.99 \$ 22.49
STRAPS					
	6254A003 #	Metal Neck Strap 1	082966 805660	PowerShot ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, ELPH 500 HS, ELPH 360 HS, ELPH 340 HS, ELPH 330 HS, ELPH 320 HS, ELPH 310 HS, ELPH 300 HS, ELPH 190 IS, ELPH 170 IS, ELPH 180, ELPH 160, ELPH 150 IS, ELPH 140 IS, ELPH 135, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, ELPH 100 HS, SD4500 IS, SD4000 IS, SD3500 IS, SD 1400 IS, SD1300 IS, SD990 IS, SD950 IS, SD900, SD970 IS, SD890 IS, SD790 IS, SD880 IS, SD870 IS, SD850 IS, SD800 IS, SD700 IS, SD980 IS, SD960 IS, SD940 IS, SD780 IS, SD1200 IS, SD770 IS, SD1100 IS, SD1000, SD750, SD630, SD600, SD550, SD500, SD110, SD100, SD450, SD400, SD430 Wireless, SD300, SD200, SD40, SD30, SD20, SD10, S500, S410, S400, S330, S300, S230, S200, S110, S100**, S80, S70, S60	\$ 16.00 \$ 14.40
BATTERY PACKS					
	9200A001 #	Battery Pack BP-511A	013803 035681	PowerShot Pro 1, Pro90 IS, G6, G5, G3, G2, G1 (See EOS Accessories for additional compatibility)	\$ 70.00 \$ 63.00
	9839B001 #	Battery Pack NB-13L	013803 247541	PowerShot G1 X Mark III, G5 X, G7 X Mark II, G7 X, G9 X Mark II, G9 X, SX720 HS, SX620 HS	\$ 59.99 \$ 53.99
	9426B001 #	Battery Pack NB-12L	013803 240573	PowerShot G1 X Mark II, N100	\$ 59.99 \$ 53.99
	9391B001 #	Battery Pack NB-11LH	013803 238266	PowerShot SX420 IS, SX410 IS, SX400 IS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 320 HS, ELPH 190 IS, ELPH 170 IS, ELPH 180, ELPH 160, ELPH 150 IS, ELPH 140 IS, ELPH 135, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, A4000 IS, A3400 IS, A2600, A2500, A2400 IS, A2300	\$ 59.99 \$ 53.99
	5668B001 #	Battery Pack NB-10L	013803 140347	PowerShot G1 X, G3 X, G16, G15, SX60 HS, SX50 HS, SX40 HS	\$ 59.99 \$ 53.99
	4722B001 #	Battery Pack NB-9L	013803 127065	PowerShot N2, N, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, SD4500 IS	\$ 59.99 \$ 53.99
	3153B001 #	Battery Pack NB-7L	013803 100730	PowerShot G12, G11, G10, SX30 IS	\$ 70.00 \$ 63.00
	8724B001 #	Battery Pack NB-6LH	013803 229387	PowerShot S120, S95, S90, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX710 HS, SX700 HS, SX280 HS, SX260 HS, SX610 HS, SX600 HS, SX170 IS, D30, D20, D10, ELPH 500 HS, SD4000 IS, SD3500 IS, SD1300 IS, SD1200 IS, SD980 IS, SD770 IS	\$ 59.99 \$ 53.99
	1135B001 #	Battery Pack NB-5L	013803 064698	PowerShot S110, S100, SX230 HS, SX210 IS, SX200 IS, SD990 IS, SD970 IS, SD950 IS, SD900, SD890 IS, SD790 IS, SD880 IS, SD870 IS, SD850 IS, SD800 IS, SD700 IS	\$ 59.99 \$ 53.99
	9763A001 #	Battery Pack NB-4L	013803 044027	PowerShot TX1, SD960 IS, SD940 IS, SD780 IS, ELPH 330 HS, ELPH 310 HS, ELPH 300 HS, SD1400 IS, ELPH 100 HS, SD400 IS, SD1100 IS, SD1000, SD750, SD630, SD600, SD450, SD400, SD430 Wireless, SD300, SD200, SD40, SD30	\$ 59.99 \$ 53.99
	9612A001 #	Battery Pack NB-2LH	013803 041613	PowerShot G9, G7, S80, S70, S60, S50, S45, S40, S30 (See EOS Accessories for additional compatibility)	\$ 70.00 \$ 63.00
	1171B002 #	Battery Pack NB4-300	013803 063622	PowerShot SX20 IS, SX10 IS, SX1 IS, SX160 IS, SX150 IS, SX130 IS, SX120 IS, SX110 IS, S5 IS, S3 IS, S2 IS, A2100 IS, A2000 IS, A1400, A1300, A1200, A1100 IS, A1000 IS, A810, A800, A720 IS, A710 IS, A700, A650 IS, A640, A630, A620, A610, A590 IS, A570 IS, A580, A560, A550, A540, A530, A520, A510, A495, A490, A480, A470, A460, A430, A410, A400, A310, A300, A200, A100, A95, A80, A85, A75, A70, A60, A40, A20, A10, E1	\$ 24.00 \$ 21.60
UNDERWATER					
NEW	2300C001 #	Waterproof Case WP-DC56	013803 295696	PowerShot G1 X Mark III (Waterproof to 130 feet)	\$ 499.99 \$ 449.99
	1361C001 #	Waterproof Case WP-DC55	013803 273014	PowerShot G7 X Mark II (Waterproof to 130 feet)	\$ 399.99 \$ 359.99
	9837B001 #	Waterproof Case WP-DC54	013803 247619	PowerShot G7 X (Waterproof to 130 feet)	\$ 399.99 \$ 359.99
	9516B001 #	Waterproof Case WP-DC53	013803 240597	PowerShot G1 X Mark II (Waterproof to 130 feet)	\$ 399.99 \$ 359.99
	8722B001 #	Waterproof Case WP-DC52	013803 230291	PowerShot G16 (Waterproof to 130 feet)	\$ 349.99 \$ 314.99
	8723B001 #	Waterproof Case WP-DC51	013803 229172	PowerShot S120 (Waterproof to 130 feet)	\$ 349.99 \$ 314.99
	6924B001 #	Waterproof Case WP-DC48	013803 158786	PowerShot G15 (Waterproof to 130 feet)	\$ 349.99 \$ 314.99
	6938B001 #	Waterproof Case WP-DC47	013803 159042	PowerShot S110 (Waterproof to 130 feet)	\$ 349.99 \$ 314.99
	5708B001 #	Waterproof Case WP-DC45	013803 147063	PowerShot D30, D20 (Waterproof to 130 feet)	\$ 329.99 \$ 296.99
	5969B001 #	Waterproof Case WP-DC44	013803 145397	PowerShot G1 X (Waterproof to 130 feet)	\$ 399.99 \$ 359.99
	5481B001 #	Waterproof Case WP-DC43	013803 138221	PowerShot S100 (Waterproof to 130 feet)	\$ 299.99 \$ 269.99
	5066B001 #	Waterproof Case WP-DC42	013803 136685	PowerShot SX230 HS (Waterproof to 130 feet)	\$ 299.99 \$ 269.99
	4712B001 #	Waterproof Case WP-DC38	013803 126761	PowerShot S95 (Waterproof to 130 feet)	\$ 299.99 \$ 269.99

	4041B001 #	Waterproof Case WP-DC35	013803 116090	PowerShot S90 (Waterproof to 130 feet)	\$ 299.99	\$ 269.99
	4042B001 #	Waterproof Case WP-DC34	013803 117578	PowerShot G12, G11 (Waterproof to 130 feet)	\$ 299.99	\$ 269.99
	3156B001 #	Waterproof Case WP-DC28	013803 100662	PowerShot G10 (Waterproof to 130 feet)	\$ 299.99	\$ 269.99
	9876A001 #	Waterproof Weight WW-DC1	013803 045666	PowerShot G1 X Mark II, G7 X, G1 X, G16, G15, G12, G11, G10, G9, S120, S110, S100, S90, S80, S70, S60, S50, S45, S40, S30, D30, D20, SD950 IS, SD900, SD880 IS, SD940 IS, SD1300 IS, SD770 IS, SD1100 IS, SD630, SD600, SD550, SD500, SD110, SD100, S500, S410, S400, S330, S300, S230, S200, A720 IS, A710 IS, A650 IS, A640, A630, A620, A610, A570 IS, A540, A520, A510, A200, A100, A95, A80, A85, A75, A70, A60, A40, A20, A10	\$ 34.00	\$ 30.60
LENSES						
Limited Quantity	8158A001 #	Wide Converter WC-DC58N (35mm equivalent to 24.5mm)	013803 020328	PowerShot G6, G5, G3, A720 IS, A710 IS, A700, A640, A630, A620, A610 (0.7x Requires Conversion Lens Adapter)	\$ 199.00	\$ 179.10
Limited Quantity	8159A001 #	Tele Converter TC-DC58N (G6, G5, G3, A640, A630, A620, A610 35mm equivalent to 22.4mm; A720 IS, A710, A700 35mm equivalent to 367.5mm)	013803 020335	PowerShot G6, G5, G3, A720 IS, A710 IS, A700, A640, A630, A620, A610 (1.75x Requires Conversion Lens Adapter)	\$ 149.00	\$ 134.10
	3152B001 #	Tele Converter TC-DC58D (35mm equivalent to 196mm)	013803 100693	PowerShot G12, G11, G10 (1.75x Requires Conversion Lens Adapter)	\$ 149.00	\$ 134.10
	6926B001 #	Tele Converter TC-DC58E (35mm equivalent to 196mm)	013803 158793	PowerShot G16, G15 (1.4x Requires Conversion Lens Adapter LA-DC58L)	\$ 249.00	\$ 224.10
	0301B001 #	Lens Adapter / Hood Set LAH-DC20	013803 053135	PowerShot S5 IS, S3 IS, S2 IS (Required for Wide Converter WC-DC58A and Tele Converter TC-DC58B)	\$ 39.00	\$ 35.10
	6927B001 #	Conversion Lens Adapter LA-DC58L	013803 158823	PowerShot G16, G15	\$ 39.00	\$ 35.10
	3151B001 #	Conversion Lens Adapter LA-DC58K	013803 100686	PowerShot G12, G11, G10 (Required for Wide Converter WC-DC58B/Tele Converter TC-DC58D)	\$ 39.00	\$ 35.10
	3206B001 #	Ring Accessory Kit RAK-DC2	013803 102420	PowerShot G12, G11, G10	\$ 27.00	\$ 24.30
LENS HOOD						
NEW	2301C001 #	Lens Hood LH-DC110	013803 295702	PowerShot G1 X Mark III	\$ 59.99	\$ 53.99
	9843B001 #	Lens Hood LH-DC90	013803 245080	PowerShot SX60 HS	\$ 29.99	\$ 26.99
	9553B001 #	Lens Hood LH-DC80	013803 241990	PowerShot G1 X Mark II	\$ 29.99	\$ 26.99
	5973B001 #	Lens Hood LH-DC70	013803 145564	PowerShot G1 X	\$ 29.99	\$ 26.99
	4727B001 #	Lens Hood LH-DC60	013803 127416	PowerShot SX50 HS, SX40 HS, SX30 IS, SX540 HS, SX530 HS, SX520 HS	\$ 25.00	\$ 22.50
KIT						
	0569C001 #	Lens Hood LH-DC100 / Filter Adapter FA-DC67B Kit	013803 257168	PowerShot G3 X	\$ 49.99	\$ 44.99
FILTER ADAPTERS						
	4721B001 #	Filter Adapter FA-DC58B	013803 127010	PowerShot G12, G11, G10	\$ 49.00	\$ 44.10
	5971B001 #	Filter Adapter FA-DC58C	013803 145540	PowerShot G1 X	\$ 29.99	\$ 26.99
	6925B001 #	Filter Adapter FA-DC58D	013803 158809	PowerShot G16, G15	\$ 49.00	\$ 44.10
	9554B001 #	Filter Adapter FA-DC58E	013803 242003	PowerShot G1 X Mark II	\$ 29.99	\$ 26.99
	4728B001 #	Filter Adapter FA-DC67A	013803 127423	PowerShot SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10, SX1 IS, SX540 HS, SX530 HS, SX520 HS	\$ 25.00	\$ 22.50
VIEWFINDER						
	9555B001	Electronic Viewfinder EVF-DC1	013803 242010	PowerShot G1 X Mark II, G3 X	\$ 299.99	\$ 269.99
FLASHES						
	1177C002	Speedlite 600EX II-RT	013803 270891	PowerShot G1 X Mark III, G1 X Mark II, G3 X, G5 X, G16, G15, SX60 HS, SX50 HS, SX40 HS (See EOS accessories for additional compatibility)	\$ 880.00	\$ 579.99
	5296B002	Speedlite 600EX-RT	013803 136692	PowerShot G1 X Mark III, G1 X Mark II, G3 X, G5 X, G16, G15, SX60 HS, SX50 HS, SX40 HS (See EOS accessories for additional compatibility)	\$ 880.00	\$ 549.99
	0585C006	Speedlite 430EX III-RT	013803 267594	PowerShot G1 X Mark III, G1 X Mark II, G3 X, G5 X, G16, SX60 HS (See EOS Accessories for additional compatibility)	\$ 480.00	\$ 299.99
	2805B002	Speedlite 430EX II	013803 099805	PowerShot Pro1, Pro90 IS, G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G11, G10, G9, G7, G6, G5, G3, G2, G1, SX1 IS, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, S5 IS (See EOS accessories for additional compatibility)	\$ 480.00	\$ 299.99
	5246B002	Speedlite 320EX	013803 136678	PowerShot Pro1, Pro90 IS, G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G11, G10, G9, G7, G6, G5, G3, G2, G1, SX1 IS, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, S5 IS (See EOS accessories for additional compatibility)	\$ 400.00	\$ 249.99
	5247B002	Speedlite 270EX II	013803 135268	PowerShot Pro1, Pro90 IS, G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G11, G10, G9, G7, G6, G5, G3, G2, G1, SX1 IS, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, S5 IS (See EOS accessories for additional compatibility)	\$ 270.00	\$ 169.99
	2357A002	Macro Twin Lite MT-24EX	082966 150432	PowerShot Pro1 (Requires LA-DC 58C), G1 X, G16/G15 (Requires LA-DC58L)/G12/G11/G10 (Requires bracket BKT-DC1), G6 (Requires LA-DC 58D and MacroLite Adapter (recommended)), G5, G3; See EOS accessories for additional compatibility)	\$ 1,400.00	\$ 829.99
	9389B002	Macro Ring Lite MR-14EX II	013803 239911	PowerShot Pro1, G1 X, G16/G15 (Requires LA-DC58L)/G12/G11/G10 (Requires bracket BKT-DC 1), G2 (When using Close-up Lens 500D or 250D w/MR-14 EX, a respective Lens Adapter and Adapter 58C are required; See EOS accessories for additional compatibility)	\$ 870.00	\$ 549.99
	2356A002	Macro Ring Lite MR-14EX	082966 150425	PowerShot Pro1, G1 X, G16/G15 (Requires LA-DC58L)/G12/G11/G10 (Requires bracket BKT-DC 1), G2 (When using Close-up Lens 500D or 250D w/MR-14 EX, a respective Lens Adapter and Adapter 58C are required; See EOS accessories for additional compatibility)	\$ 870.00	\$ 549.99
	5970B001 #	MacroLite Adapter MLA-DC1	013803 145557	PowerShot G1 X	\$ 29.99	\$ 26.99
	3412B001 #	Bracket BKT-DC1	013803 111477	PowerShot G1 X Mark II, G1 X, G16, G15, G12, G11, G10, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, SX1 IS	\$ 64.99	\$ 58.49
	9940A001 #	High-Power Flash HF-DC1	013803 046137	Compatible with all PowerShot cameras except G1 X Mark III, G1 X Mark II, G1 X, G5 X, G9 X, S120, S110, S100, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX530 HS, SX510 HS, SX500 IS, SX280 HS, SX260 HS, SX720 HS, SX710 HS, SX700 HS, SX610 HS, SX600 HS, SX410 IS, N100, N2, N, ELPH 500 HS, ELPH 350 HS, ELPH 340 HS, ELPH 330 HS, ELPH 320 HS, ELPH 300 HS, ELPH 170 IS, ELPH 160, ELPH 150 IS, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, SD3500 IS SD1400 IS, 600	\$ 129.99	\$ 116.99
	5189B001 #	High-Power Flash HF-DC2	013803 134865	Compatible with all PowerShot cameras except G1 X Mark III, G1 X Mark II, G1 X, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, SX1 IS, SX710, SX700 HS, PowerShot N2, N	\$ 149.99	\$ 134.99
	5743B002 #	Speedlite Transmitter ST-E3-RT	013803 142488	PowerShot G1 X Mark III, G3 X, G5 X	\$ 470.00	\$ 423.00

2478A002 #	Speedlite Transmitter ST-E2	082966 581533	PowerShot Pro1, G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G11, G10, G9, G7, G6, G5, G3, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS (See EOS accessories for additional compatibility)	\$ 350.00	\$ 315.00
1950B001 #	Off-Camera Shoe Cord OC-E3	013803 078879	PowerShot Pro1, G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G11, G10, G9, G7, G2, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS (See EOS accessories for additional compatibility)	\$ 100.00	\$ 90.00
2365A001 #	MacroLite Adapter 58C	082966 581137	PowerShot Pro1, G2 (See EOS accessories for additional compatibility)	\$ 17.00	\$ 15.30
AC ADAPTERS AND CHARGERS					
7875A002 #	Compact Power Adapter CA-PS700	013803 015751	PowerShot G1 X Mark II, G1 X, G16, G15, S80, SX1 IS, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, S5 IS, S3 IS, S2 IS, (See EOS accessories for additional compatibility)	\$ 65.00	\$ 58.50
0992C001 #	Compact Power Adapter CA-DC30	013803 267921	PowerShot G1 X Mark III, G5 X, G7 X Mark II*, G9 X Mark II*, G9 X*, SX720 HS*, N2**, N** * USB Cable IFC-600PCU is necessary. ** USB Cable IFC-400PCU is necessary.	\$ 40.00	\$ 36.00
7873A002#	Car Battery Charger CBC-NB2	013803 015935	PowerShot G9, G7, S80, S70, S60, S50, S45, S40, S30	\$ 125.00	\$ 112.50
7640A001 #	AC Adapter Kit ACK-800	013803 011616	PowerShot SX160 IS, SX150 IS, SX130 IS, SX120 IS, SX110 IS, A2100 IS, A2000 IS, A1300, A1200, A1100 IS, A1000 IS, A1400, A810, A800, A720 IS, A710 IS, A700, A590 IS, A570 IS, A580, A560, A550, A540, A530, A520, A510, A495, A490, A480, A470, A460, A430, A410, A400, A310, A300, A200, A100, E1 (Includes: Compact Power Adapter CA-PS800, Power Cable)	\$ 49.00	\$ 44.10
9838B001	AC Adapter KIT ACK-DC110	013803 247626	PowerShot G5 X, G7 X, G9 X Mark II, G9 X	\$ 70.00	\$ 63.00
9535B001 #	AC Adapter Kit ACK-DC100	013803 246005	PowerShot G1 X Mark II, N100	\$ 70.00	\$ 63.00
6216B001 #	AC Adapter Kit ACK-DC90	013803 146936	PowerShot SX420 IS, SX410 IS, SX400 IS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 320 HS, ELPH 190 IS, ELPH 170 IS, ELPH 180, ELPH 160, ELPH 150 IS, ELPH 140 IS, ELPH 135, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, A4000 IS, A2600, A2500, A3400 IS, A2400 IS, A2300	\$ 70.00	\$ 63.00
5667B001 #	AC Adapter Kit ACK-DC80	013803 140194	PowerShot G1 X, G3 X, G16, G15, SX60 HS, SX50 HS, SX40 HS	\$ 70.00	\$ 63.00
4726B001 #	AC Adapter Kit ACK-DC70	013803 127126	PowerShot N2, N, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, SD4500 IS	\$ 70.00	\$ 63.00
4266B001 #	AC Adapter Kit ACK-DC60	013803 120189	PowerShot TX1, SD960 IS, SD940 IS, SD780 IS, ELPH 330 HS, ELPH 310 HS, ELPH 300 HS, SD1400 IS, SD770 IS, SD1100, SD1000, SD750, SD630, SD600, SD450, SD400, SD430 Wireless, SD300, SD200, SD40, SD30, A3300 IS, A3100 IS, A3000 IS, A2200	\$ 70.00	\$ 63.00
2610B001 #	AC Adapter Kit ACK-DC40	013803 091229	PowerShot S120, S95, S90, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX710 HS, SX700 HS, SX280 HS, SX260 HS, SX610 HS, SX600 HS, SX170 IS, D30, D20, D10, ELPH 500 HS, SD4000 IS, SD3500 IS, SD980 IS, SD1300 IS, SD1200 IS, SD770 IS	\$ 70.00	\$ 63.00
1137B001 #	AC Adapter Kit ACK-DC30	013803 064711	PowerShot S110, S100, SX230 HS, SX210 IS, SX200 IS, SD990 IS, SD950 IS, SD900, SD970 IS, SD890 IS, SD790 IS, SD880 IS, SD870 IS, SD850 IS, SD800 IS, SD700 IS	\$ 70.00	\$ 63.00
0766B001 #	AC Adapter Kit ACK-DC20	013803 057478	PowerShot G9, G7, S80, S70, S60, S50, S45, S40, S30 (Includes Compact Power Adapter CA-PS700, DC Coupler DR-700/DR-200, Power Cable)	\$ 70.00	\$ 63.00
5190B001 #	DC Coupler DR-DC10	013803 135084	PowerShot SX160 IS, SX150 IS, A1400, A1300, A810, A800 (A1400, A1300, A810, A800 used with ACK-800)	\$ 22.00	\$ 19.80
9840B001 #	Battery Charger CB-2LH	013803 247602	PowerShot G1 X Mark III, G5 X, G7 X Mark II, G7 X, G9 X Mark II, G9 X, SX720 HS, SX620 HS	\$ 50.00	\$ 45.00
9513B001 #	Battery Charger CB-2LG	013803 240580	PowerShot G1 X Mark II, N100	\$ 50.00	\$ 45.00
8419B001 #	Battery Charger CB-2LF	013803 217148	PowerShot SX420 IS, SX410 IS, SX400 IS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 320 HS, ELPH 190 IS, ELPH 170 IS, ELPH 180, ELPH 160, ELPH 150 IS, ELPH 140 IS, ELPH 135, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, A4000 IS, A2600, A2500, A3400 IS, A2400 IS, A2300	\$ 50.00	\$ 45.00
5669B001 #	Battery Charger CB-2LC	013803 140354	PowerShot G1 X, G3 X, G16, G15, SX60 HS, SX50 HS, SX40 HS	\$ 50.00	\$ 45.00
4723B001 #	Battery Charger CB-2LB	013803 127072	PowerShot N2, N, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, SD4500 IS	\$ 50.00	\$ 45.00
3154B001 #	Battery Charger CB-2LZ	013803 100709	PowerShot G12, G11, G10, SX30 IS	\$ 50.00	\$ 45.00
2608B001 #	Battery Charger CB-2LY	013803 091212	PowerShot S120, S95, S90, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX710 HS, SX700 HS, SX280 HS, SX260 HS, SX610 HS, SX600 HS, SX170 IS, D30, D20, D10, ELPH 500 HS, SD4000 IS, SD3500 IS, SD980 IS, SD1300 IS, SD1200 IS, SD770 IS	\$ 50.00	\$ 45.00
1133B001 #	Battery Charger CB-2LX	013803 064704	PowerShot S110, S100, SX230 HS, SX210 IS, SX200 IS, SD990 IS, SD950 IS, SD900, SD970 IS, SD890 IS, SD790 IS, SD880 IS, SD870 IS, SD850 IS, SD800 IS, SD700 IS	\$ 50.00	\$ 45.00
0763B001 #	Battery Charger CB-2LW	013803 057461	PowerShot G9, G7, S80, S70, S60, S50, S45, S40, S30 (Replacement of CB-2LT)	\$ 55.00	\$ 49.50
9764A001 #	Battery Charger CB-2LV	013803 044034	PowerShot TX1, SD960 IS, SD940 IS, SD780 IS, ELPH 330 HS, ELPH 310 HS, ELPH 300 HS, SD1400 IS, ELPH 100 HS, SD1100 IS, SD1000, SD750, SD630, SD600, SD450, SD400, SD430 Wireless, SD300, SD200, SD40, SD30	\$ 50.00	\$ 45.00
1169B001 #	Battery & Charger Kit CBK4-300	013803 063615	PowerShot SX20 IS, SX10 IS, SX1 IS, SX160 IS, SX150 IS, SX130 IS, SX120 IS, SX110 IS, S5 IS, S3 IS, S2 IS, S1 IS, A2100 IS, A2000 IS, A1100 IS, A1000 IS, A1400, A1300, A1200, A810, A800, A720 IS, A710 IS, A700, A650 IS, A640, A630, A620, A610, A590 IS, A570 IS, A580, A560, A550, A540, A530, A520, A510, A495, A490, A480, A470, A460, A430, A410, A400, A310, A300, A200, A100, A95, A80, A85, A75, A70, A60, A40, A20, A10, E1 (Four AA-size NiMH batteries and charger CB-4AH)	\$ 58.00	\$ 52.20
CABLES					
1015C001 #	USB Cable IFC-600PCU	013803 267877	PowerShot G1 X Mark III, G5 X, G7 X Mark II, G9 X Mark II, G9 X, SX720 HS, SX620 HS	\$ 16.00	\$ 14.40
9370A001 #	USB Cable IFC-400PCU	013803 038361	All PowerShot cameras except Pro90 IS, Pro70, G1 X Mark III, G2, G1, SD10, S230, S200, S110, S100**, S20, S10, A50, 600, A5 Zoom, A5 (See EOS accessories for additional compatibility)	\$ 16.00	\$ 14.40
2384B001 #	Mini-HDMI Cable HTC-100	013803 086737	PowerShot G1 X, G3 X, G16, G15, G12, G11, S120, S110, S100, S95, S90, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, SX1 IS, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX280 HS, SX260 HS, SX230 HS, SX210 IS, SX200 IS, SX160 IS, D30, D20, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, ELPH 500 HS, ELPH 330 HS, ELPH 320 HS, SD4500 IS, SD4000 IS, SD3500 IS, ELPH 310 HS, ELPH 300 HS, SD1400 IS, ELPH 110 HS, ELPH 100 HS, SD970 IS, SD980 IS, SD960 IS, SD940 IS, SD780 IS	\$ 80.00	\$ 72.00

4076B001 #	Stereo AV Cable AVC-DC400ST	013803 119343	PowerShot G1 X Mark II, G1 X, G7 X, G16, G15, G12, S120, S110, S100, S95, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX710 HS, SX700 HS, SX280 HS, SX260 HS, SX230 HS, SX210 IS, SX170 IS, SX160 IS, SX150 IS, SX130 IS, N100, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, ELPH 500 HS, ELPH 330 HS, ELPH 320 HS, ELPH 310 HS, ELPH 300 HS, SD4500 IS, SD4000 IS	\$ 25.00	\$ 22.50
2563B001 #	AV Cable AVC-DC400	013803 090826	PowerShot G11, S90, SX610 HS, SX600 HS, SX420 IS, SX410 IS, SX400 IS, SX200 IS, SX120 IS, SX110 IS, D30, D20, D10, SD4500 IS, SD4000 IS, SD3500 IS, SD990 IS, SD970 IS, SD890 IS, SD880 IS, SD790 IS, SD980 IS, SD960 IS, SD940 IS, SD780 IS, SD1400 IS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 190 IS, ELPH 170 IS, ELPH 180, ELPH 160, ELPH 150 IS, ELPH 140 IS, ELPH 135, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, ELPH 100 HS, SD1200 IS, SD770 IS, A4000 IS, A3400 IS, A3300 IS, A3100 IS, A3000 IS, A2600, A2500, A2400 IS, A2300, A2100 IS, A2000 IS, A1400, A1300, A1100 IS, A1000 IS, A810, E1	\$ 16.00	\$ 14.40
9371A001 #	AV Cable AVC-DC300	013803 038378	PowerShot Pro1, Pro90 IS, G10, G9, G7, G6, G5, G3, G2, G1, S80, S70, S60, S50, S45, S40, S30, SX160 IS, SX150 IS, SX130 IS, SX120 IS, SX110 IS, SD950 IS, SD900, SD870 IS, SD850 IS, SD800 IS, SD700 IS, SD1100 IS, SD1000, SD750, SD630, SD600, SD550, SD500, SD110, SD100, SD450, SD400, SD430 Wireless, SD300, SD200, SD40, SD30, SD20, SD10, S500, S410, S400, S330, S300, S230, S200, S110, S100**, A2200, A2100 IS, A2000 IS, A1100 IS, A1000 IS, A1200, A720 IS, A710 IS, A700, A650 IS, A640, A630, A620, A610, A590, IS, A570 IS, A580, A560, A550, A540, A520, A510, A530, A800, A495, A 490, A480, A470, A460, A430, A410, A400, A85, A75, A70, A60, A40	\$ 16.00	\$ 14.40
3067A002 #	Stereo Video Cable STV-250N	013803 605983	PowerShot SX150 IS, SX20 IS, SX10 IS, SX1 IS, S5 IS, S3 IS, S2 IS, TX1 (See EOS accessories for additional compatibility)	\$ 22.00	\$ 19.80
1719B001 #	Component Cable CTC-100	13803 074321	PowerShot TX1	\$ 50.00	\$ 45.00
2477A002 #	Timer Remote Control TC-80N3	082966 581564	PowerShot G1 X Mark III (See EOS accessories for additional compatibility)	\$ 210.00	\$ 189.00
1157C001 #	Remote Controller Adapter RA-E3	013803 270549	PowerShot G1 X Mark III (See EOS accessories for additional compatibility)	\$ 45.00	\$ 40.50
CONTROLLER					
2469A002 #	Remote Switch RS-60E3	082966 581359	PowerShot G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G10, G11, SX60 HS, SX50 HS	\$ 30.00	\$ 27.00