

Video						
Digital Cameras						
Applied Video Systems, Inc.				Canon PowerShot Digital Cameras		
5816-D Shakespeare Road						
Columbia SC 29223				Contract # 4400013015		
803-735-1120, 800-325-2281						
Fax: 803-735-1121				Effective 7-11-19		
sales@appliedvideosystems.com						
www.appliedvideosystems.com						
	ITEM CODE NO.	PRODUCT DESCRIPTION		SUGG. LIST PRICE (\$)	CONTRACT	
POWERSHOT G SERIES						
	2208C001	PowerShot G1 X Mark III Kit (Black)	PowerShot G1 X Mark III, Battery Pack NB-13L, Battery Charger CB-2LH, Neck Strap NS-DC12, Strap Adapters	\$ 1,700.00	\$	1,360.00
	9167B001	PowerShot G1 X Mark II Kit (Black)	PowerShot G1 X Mark II, Battery Pack NB-12L, Battery Charger CB-2LG, Neck Strap NS-DC11	\$ 899.99	\$	798.00
	0106C001	PowerShot G3 X Kit (Black)	PowerShot G3 X, Battery Pack NB-10L, Battery Charger CB-2LC, Lens Cap (with Strap), Neck Strap NS-DC11	\$ 1,099.99	\$	879.99
NEW	3070C001	PowerShot G5 X Mark II Kit (Black)	PowerShot G5 X Mark II, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 999.99	\$	898.99
	0510C001	PowerShot G5 X Kit (Black)	PowerShot G5 X, Battery Pack NB-13L, Battery Charger CB-2LH, Neck Strap NS-DC12, Strap Adapters	\$ 899.99	\$	798.99
NEW	3638C001	PowerShot G7 X Mark III Kit (Silver)	PowerShot G7 X Mark III, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 849.99	\$	748.99
NEW	3637C001	PowerShot G7 X Mark III Kit (Black)	PowerShot G7 X Mark III, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 849.99	\$	748.99
	1066C001	PowerShot G7 X Mark II Kit (Black)	PowerShot G7 X Mark II, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 799.99	\$	698.99
	1066C029	PowerShot G7 X Mark II Video Creator Kit (Black)	PowerShot G7 X Mark II, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12, Manfrotto™ PIXI Mini Tripod (Black), 32GB Class 10 SDHC Memory Card, Extra Battery Pack NB-13L	\$ 849.99	\$	849.99
	1718C001	PowerShot G9 X Mark II (Silver)	PowerShot G9 X Mark II, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 629.99	\$	503.99
	1717C001	PowerShot G9 X Mark II (Black)	PowerShot G9 X Mark II, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 629.99	\$	503.99
	0924C001	PowerShot G9 X Kit (Silver)	PowerShot G9 X, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 629.99	\$	528.99
	0511C001	PowerShot G9 X Kit (Black)	PowerShot G9 X, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-DC12	\$ 629.99	\$	528.99
POWERSHOT SX SERIES						
	3071C001	PowerShot SX70 HS Kit (Black)	PowerShot SX70 HS, Battery Pack LP-E12, Battery Charger LC-E12, Lens Cap (with Strap), Neck Strap NS-DC11	\$ 649.99	\$	548.99
	9543B001	PowerShot SX60 HS Kit (Black)	PowerShot SX60 HS, Battery Pack NB-10L, Battery Charger CB-2LC, Lens Cap (with Strap), Neck Strap NS-DC11	\$ 649.99	\$	548.99
NEW MAP & D/N PRICE	1067C001	PowerShot SX540 HS Kit (Black)	PowerShot SX540 HS, Battery Pack NB-6LH, Battery Charger CB-2LY, Lens Cap (with Strap), Neck Strap NS-DC11	\$ 429.99	\$	343.99
	9779B001	PowerShot SX530 HS Kit (Black)	PowerShot SX530 HS, Battery Pack NB-6LH, Battery Charger CB-2LY, Lens Cap (with Strap), Neck Strap NS-DC11	\$ 479.99	\$	315.99
	2955C001	PowerShot SX740 HS Kit (Black)	PowerShot SX740 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 499.99	\$	399.99
	2956C001	PowerShot SX740 HS Kit (Silver)	PowerShot SX740 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 499.99	\$	399.99
	1791C001	PowerShot SX730 HS Kit (Black)	PowerShot SX730 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 499.99	\$	399.99
	1792C001	PowerShot SX730 HS Kit (Silver)	PowerShot SX730 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-801	\$ 499.99	\$	399.99
	1070C001	PowerShot SX720 HS Kit (Black)	PowerShot SX720 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 479.99	\$	383.99
	0109C001	PowerShot SX710 HS Kit (Black)	PowerShot SX710 HS, Battery Pack NB-6LH, Battery Charger CB-2LY, Wrist Strap WS-800	\$ 449.99	\$	359.99
	1073C001	PowerShot SX620 HS Kit (Red)	PowerShot SX620 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 379.99	\$	303.99
	1072C001	PowerShot SX620 HS Kit (Black)	PowerShot SX620 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 379.99	\$	303.99
	1074C001	PowerShot SX620 HS Kit (Silver)	PowerShot SX620 HS, Battery Pack NB-13L, Battery Charger CB-2LH, Wrist Strap WS-800	\$ 379.99	\$	303.99
	1068C001	PowerShot SX420 IS Kit (Black)	PowerShot SX420 IS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-DC12	\$ 399.99	\$	319.99
	1069C001	PowerShot SX420 IS Kit (Red)	PowerShot SX420 IS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-DC12	\$ 399.99	\$	319.99
POWERSHOT D SERIES						
	9337B001	PowerShot D30 Kit (Blue)	PowerShot D30, Battery Pack NB-6LH, Battery Charger CB-2LY, Wrist Strap WS-DC8	\$ 429.99	\$	343.99
POWERSHOT N SERIES						
	9168B001	PowerShot N100 Kit (Black)	PowerShot N100, Battery Pack NB-12L, Battery Charger CB-2LG, Wrist Strap WS-DC12	\$ 449.99	\$	359.99
POWERSHOT DIGITAL ELPH SERIES						
	1081C001	PowerShot ELPH 360 HS Kit (Purple)	PowerShot ELPH 360 HS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 309.99	\$	247.99
	1078C001	PowerShot ELPH 360 HS Kit (Silver)	PowerShot ELPH 360 HS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 309.99	\$	247.99
	1075C001	PowerShot ELPH 360 HS Kit (Black)	PowerShot ELPH 360 HS, Battery Pack NB-11LH, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 309.99	\$	247.99
	1090C001	PowerShot ELPH 190 IS Kit (Blue)	PowerShot ELPH 190 IS, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 259.99	\$	207.99
	1084C001	PowerShot ELPH 190 IS Kit (Black)	PowerShot ELPH 190 IS, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 259.99	\$	207.99

	1087C001	PowerShot ELPH 190 IS Kit (Red)	PowerShot ELPH 190 IS, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 259.99	\$ 207.99
	1093C001	PowerShot ELPH 180 Kit (Silver)	PowerShot ELPH 180, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 219.99	\$ 175.99
	1096C001	PowerShot ELPH 180 Kit (Red)	PowerShot ELPH 180, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 219.99	\$ 175.99
	0143C001	PowerShot ELPH 160 Kit (Red)	PowerShot ELPH 160, Battery Pack NB-11L, Battery Charger CB-2LF, Wrist Strap WS-800	\$ 219.99	\$ 175.99
CONNECT STATION					
	9899B002 #	Connect Station CS100	#####	\$ 480.00	\$ 384.00
CASES					
NEW	3088C028 #	Compact Camera Case EDC-100	Compatible with PowerShot cameras, excluding PowerShot G1 X MarkIII, PowerShot G3 X, PowerShot SX70HS, PowerShot SX60HS, PowerShot SX540HS, PowerShot SX530 HS	\$ 19.99	\$ 17.99
	3087C001 #	Deluxe Leather Case PSC-6300	PowerShot G1 X Mark III	\$ 99.99	\$ 89.99
	1023C001 #	Deluxe Leather Case PSC-6200	PowerShot G3 X	\$ 79.99	\$ 71.99
	9874B001 #	Deluxe Soft Case PSC-6100	PowerShot G1 X Mark II	\$ 69.99	\$ 62.99
	1709C001 #	Deluxe Leather Case PSC-5600	PowerShot G9 X Mark II, G9 X	\$ 39.99	\$ 35.99
	1625C001 #	Deluxe Leather Case PSC-5500	PowerShot G7 X Mark II, G7 X	\$ 59.99	\$ 53.99
	1282C001 #	Deluxe Leather Case PSC-5400	PowerShot G5 X	\$ 59.99	\$ 53.99
	0448C001 #	Deluxe Leather Case PSC-5300BK	PowerShot G7 X	\$ 59.99	\$ 53.99
	0235C001 #	Deluxe Soft Case PSC-4200	PowerShot SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, SX1 IS, SX540 HS, SX530 HS, SX520 HS	\$ 29.99	\$ 26.99
	8059B001 #	Deluxe Soft Case PSC-4050	PowerShot SX510 HS, SX500 IS, SX420 IS, SX410 IS, SX400 IS	\$ 24.99	\$ 22.49
	5021B001 #	Deluxe Soft Case PSC-3300	PowerShot G7 X, G9 X Mark II, G9 X, SX740 HS, SX730 HS, SX720 HS, SX710 HS, SX700 HS, SX620 HS, SX610 IS, SX600 HS, SX280 HS, SX260 HS, SX170 IS, SX160 IS, SX150 IS, SX130 IS, SX120 IS, SX110 IS, N100	\$ 19.99	\$ 17.99
	4854B001 #	Deluxe Leather Case PSC-3200	PowerShot S120, S110, S100, S95, S90, SX280 HS, SX260 HS, SX230 HS, SX210 IS, SX620 HS, SX610 HS, SX600 HS, ELPH 510 HS, ELPH 500 HS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 190 IS, ELPH 170 IS, ELPH 330 HS, SD4500 IS, A4000 IS	\$ 24.99	\$ 22.49
STRAPS					
BATTERY PACKS					
	9200A001 #	Battery Pack BP-511A	PowerShot Pro 1, Pro90 IS, G6, G5, G3, G2, G1 (See EOS Accessories for additional compatibility)	\$ 70.00	\$ 63.00
	9839B001 #	Battery Pack NB-13L	PowerShot G1 X Mark III, G5 X, G7 X Mark II, G7 X, G9 X Mark II, G9 X, SX740 HS, SX730 HS, SX720 HS, SX620 HS	\$ 59.99	\$ 53.99
	9426B001 #	Battery Pack NB-12L	PowerShot G1 X Mark II, N100	\$ 59.99	\$ 53.99
	9391B001 #	Battery Pack NB-11LH	PowerShot SX420 IS, SX410 IS, SX400 IS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 320 HS, ELPH 190 IS, ELPH 170 IS, ELPH 180, ELPH 160, ELPH 150 IS, ELPH 140 IS, ELPH 135, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, A4000 IS, A3400 IS, A2600, A2500, A2400 IS, A2300	\$ 59.99	\$ 53.99
	5668B001 #	Battery Pack NB-10L	PowerShot G1 X, G3 X, G16, G15, SX60 HS, SX50 HS, SX40 HS	\$ 59.99	\$ 53.99
	4722B001 #	Battery Pack NB-9L	PowerShot N2, N, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, SD4500 IS	\$ 59.99	\$ 53.99
	3153B001 #	Battery Pack NB-7L	PowerShot G12, G11, G10, SX30 IS	\$ 70.00	\$ 63.00
	8724B001 #	Battery Pack NB-6LH	PowerShot S120, S95, S90, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX710 HS, SX700 HS, SX280 HS, SX260 HS, SX610 HS, SX600 HS, SX170 IS, D30, D20, D10, ELPH 500 HS, SD4000 IS, SD3500 IS, SD1300 IS, SD1200 IS, SD980 IS, SD770 IS	\$ 59.99	\$ 53.99
	1135B001 #	Battery Pack NB-5L	PowerShot S110, S100, SX230 HS, SX210 IS, SX200 IS, SD990 IS, SD970 IS, SD950 IS, SD900, SD890 IS, SD790 IS, SD880 IS, SD870 IS, SD850 IS, SD800 IS, SD700 IS	\$ 59.99	\$ 53.99
	9763A001 #	Battery Pack NB-4L	PowerShot TX1, SD960 IS, SD940 IS, SD780 IS, ELPH 330 HS, ELPH 310 HS, ELPH 300 HS, SD1400 IS, ELPH 100 HS, SD400 IS, SD1100 IS, SD1000, SD750, SD630, SD600, SD450, SD400, SD430 Wireless, SD300, SD200, SD40, SD30	\$ 59.99	\$ 53.99
	9612A001 #	Battery Pack NB-2LH	PowerShot G9, G7, S80, S70, S60, S50, S45, S40, S30 (See EOS Accessories for additional compatibility)	\$ 70.00	\$ 63.00
	1171B002 #	Battery Pack NB4-300	PowerShot SX20 IS, SX10 IS, SX1 IS, SX160 IS, SX150 IS, SX130 IS, SX120 IS, SX110 IS, S5 IS, S3 IS, S2 IS, A2100 IS, A2000 IS, A1400, A1300, A1200, A1100 IS, A1000 IS, A810, A800, A720 IS, A710 IS, A700, A650 IS, A640, A630, A620, A610, A590 IS, A570 IS, A580, A560, A550, A540, A530, A520, A510, A495, A490, A480, A470, A460, A430, A410, A400, A310, A300, A200, A100, A95, A80, A85, A75, A70, A60, A40, A20, A10, E1	\$ 24.00	\$ 21.60
UNDERWATER					
	2300C001 #	Waterproof Case WP-DC56	PowerShot G1 X Mark III (Waterproof to 130 feet)	\$ 499.99	\$ 424.99
	1361C001 #	Waterproof Case WP-DC55	PowerShot G7 X Mark II (Waterproof to 130 feet)	\$ 399.99	\$ 339.99
	9837B001 #	Waterproof Case WP-DC54	PowerShot G7 X (Waterproof to 130 feet)	\$ 399.99	\$ 339.99
	9516B001 #	Waterproof Case WP-DC53	PowerShot G1 X Mark II (Waterproof to 130 feet)	\$ 399.99	\$ 339.99
	8722B001 #	Waterproof Case WP-DC52	PowerShot G16 (Waterproof to 130 feet)	\$ 349.99	\$ 297.49
	8723B001 #	Waterproof Case WP-DC51	PowerShot S120 (Waterproof to 130 feet)	\$ 349.99	\$ 297.49
	6924B001 #	Waterproof Case WP-DC48	PowerShot G15 (Waterproof to 130 feet)	\$ 349.99	\$ 297.49
	6938B001 #	Waterproof Case WP-DC47	PowerShot S110 (Waterproof to 130 feet)	\$ 349.99	\$ 297.49
	5708B001 #	Waterproof Case WP-DC45	PowerShot D30, D20 (Waterproof to 130 feet)	\$ 329.99	\$ 280.49
	5969B001 #	Waterproof Case WP-DC44	PowerShot G1 X (Waterproof to 130 feet)	\$ 399.99	\$ 339.99
	5481B001 #	Waterproof Case WP-DC43	PowerShot S100 (Waterproof to 130 feet)	\$ 299.99	\$ 254.99
	5066B001 #	Waterproof Case WP-DC42	PowerShot SX230 HS (Waterproof to 130 feet)	\$ 299.99	\$ 254.99
	4712B001 #	Waterproof Case WP-DC38	PowerShot S95 (Waterproof to 130 feet)	\$ 299.99	\$ 254.99

	4041B001 #	Waterproof Case WP-DC35	PowerShot S90 (Waterproof to 130 feet)	\$ 299.99	\$ 254.99
	4042B001 #	Waterproof Case WP-DC34	PowerShot G12, G11 (Waterproof to 130 feet)	\$ 299.99	\$ 254.99
	9876A001 #	Waterproof Weight WW-DC1	PowerShot G1 X Mark III, G7 X, G1 X, G16, G15, G12, G11, G10, G9, S120, S110, S100, S90, S80, S70, S60, S50, S45, S40, S30, D30, D20, SD950 IS, SD900, SD880 IS, SD940 IS, SD1300 IS, SD770 IS, SD1100 IS, SD630, SD600, SD550, SD500, SD110, SD100, S500, S410, S400, S330, S300, S230, S200, A720 IS, A710 IS, A650 IS, A640, A630, A620, A610, A570 IS, A540, A520, A510, A200, A100, A95, A80, A85, A75, A70, A60, A40, A20, A10	\$ 34.00	\$ 30.60
LENSES					
	3152B001 #	Tele Converter TC-DC58D (35mm equivalent to 196mm)	PowerShot G12, G11, G10 (1.75x Requires Conversion Lens Adapter)	\$ 149.00	\$ 134.10
	6926B001 #	Tele Converter TC-DC58E (35mm equivalent to 196mm)	PowerShot G16, G15 (1.4x Requires Conversion Lens Adapter LA-DC58L)	\$ 249.00	\$ 224.10
	6927B001 #	Conversion Lens Adapter LA-DC58L	PowerShot G16, G15	\$ 39.00	\$ 35.10
LENS HOOD					
	2301C001 #	Lens Hood LH-DC110	PowerShot G1 X Mark III	\$ 59.99	\$ 53.99
	9843B001 #	Lens Hood LH-DC90	PowerShot SX60 HS	\$ 29.99	\$ 26.99
	9553B001 #	Lens Hood LH-DC80	PowerShot G1 X Mark II	\$ 29.99	\$ 26.99
	5973B001 #	Lens Hood LH-DC70	PowerShot G1 X	\$ 29.99	\$ 26.99
	4727B001 #	Lens Hood LH-DC60	PowerShot SX50 HS, SX40 HS, SX30 IS, SX540 HS, SX530 HS, SX520 HS	\$ 25.00	\$ 22.50
KIT					
	0569C001 #	Lens Hood LH-DC100 / Filter Adapter FA-DC67B Kit	PowerShot G3 X	\$ 49.99	\$ 44.99
FILTER ADAPTERS					
	4721B001 #	Filter Adapter FA-DC58B	PowerShot G12, G11, G10	\$ 49.00	\$ 44.10
	5971B001 #	Filter Adapter FA-DC58C	PowerShot G1 X	\$ 29.99	\$ 26.99
	6925B001 #	Filter Adapter FA-DC58D	PowerShot G16, G15	\$ 49.00	\$ 44.10
	9554B001 #	Filter Adapter FA-DC58E	PowerShot G1 X Mark II	\$ 29.99	\$ 26.99
	4728B001 #	Filter Adapter FA-DC67A	PowerShot SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10, SX1 IS, SX540 HS, SX530 HS, SX520 HS	\$ 25.00	\$ 22.50
VIEWFINDER					
	9555B001	Electronic Viewfinder EVF-DC1	PowerShot G1 X Mark II, G3 X	\$ 299.99	\$ 269.99
FLASHES					
	1177C002	Speedlite 600EX II-RT	PowerShot G1 X Mark III, G1 X Mark II, G3 X, G5 X, G16, G15, SX60 HS, SX50 HS, SX40 HS (See EOS accessories for additional compatibility)	\$ 880.00	\$ 704.00
	5296B002	Speedlite 600EX-RT	PowerShot G1 X Mark III, G1 X Mark II, G3 X, G5 X, G16, G15, SX60 HS, SX50 HS, SX40 HS (See EOS accessories for additional compatibility)	\$ 880.00	\$ 704.00
	0585C006	Speedlite 430EX III-RT	PowerShot G1 X Mark III, G1 X Mark II, G3 X, G5 X, G16, SX60 HS (See EOS Accessories for additional compatibility)	\$ 480.00	\$ 384.00
	2805B002	Speedlite 430EX II	PowerShot Pro1, Pro90 IS, G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G11, G10, G9, G7, G6, G5, G3, G2, G1, SX1 IS, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, S5 IS (See EOS accessories for additional compatibility)	\$ 480.00	\$ 384.00
	5247B002	Speedlite 270EX II	PowerShot Pro1, Pro90 IS, G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G11, G10, G9, G7, G6, G5, G3, G2, G1, SX1 IS, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, S5 IS (See EOS accessories for additional compatibility)	\$ 270.00	\$ 216.00
	2357A002	Macro Twin Lite MT-24EX	PowerShot Pro1 (Requires LA-DC 58C), G1 X, G16/G15 (Requires LA-DC58L)/G12/ G11/G10 (Requires bracket BKT-DC1), G6 (Requires LA-DC 58D and Macrolite Adapter (recommended)), G5, G3; See EOS accessories for additional compatibility)	\$ 1,400.00	\$ 1,120.00
	9389B002	Macro Ring Lite MR-14EX II	PowerShot Pro1, G1 X, G16/G15 (Requires LA-DC58L)/ G12/G11/G10 (Requires bracket BKT-DC 1), G2 (When using Close-up Lens 500D or 250D w/MR-14 EX, a respective Lens Adapter and Adapter 58C are required; See EOS accessories for additional compatibility)	\$ 870.00	\$ 696.00
	5970B001 #	Macrolite Adapter MLA-DC1	PowerShot G1 X	\$ 29.99	\$ 26.99
	3412B001 #	Bracket BKT-DC1	PowerShot G1 X Mark II, G1 X, G16, G15, G12, G11, G10, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, SX1 IS	\$ 64.99	\$ 58.49
	9940A001 #	High-Power Flash HF-DC1	Compatible with all PowerShot cameras except G1 X Mark III, G1 X Mark II, G1 X, G5 X, G9 X, S120, S110, S100, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX530 HS, SX510 HS, SX500 IS, SX280 HS, SX260 HS, SX720 HS, SX710 HS, SX700 HS, SX610 HS, SX600 HS, SX410 IS, N100, N2, N, ELPH 500 HS, ELPH 350 HS, ELPH 340 HS, ELPH 330 HS, ELPH 320 HS, ELPH 300 HS, ELPH 170 IS, ELPH 160, ELPH 150 IS, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, SD3500 IS SD1400 IS, 600	\$ 129.99	\$ 116.99
	5189B001 #	High-Power Flash HF-DC2	Compatible with all PowerShot cameras except G1 X Mark III, G1 X Mark II, G1 X, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, SX1 IS, SX710, SX700 HS, PowerShot N2, N	\$ 149.99	\$ 134.99
	5743B002 #	Speedlite Transmitter ST-E3-RT	PowerShot G1 X Mark III, G3 X, G5 X	\$ 470.00	\$ 423.00
	2478A002 #	Speedlite Transmitter ST-E2	PowerShot Pro1, G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G11, G10, G9, G7, G6, G5, G3, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS (See EOS accessories for additional compatibility)	\$ 350.00	\$ 315.00
	1950B001 #	Off-Camera Shoe Cord OC-E3	PowerShot Pro1, G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G11, G10, G9, G7, G2, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS (See EOS accessories for additional compatibility)	\$ 100.00	\$ 90.00

	2365A001 #	Macrolite Adapter 58C	PowerShot Pro1, G2 (See EOS accessories for additional compatibility)	\$ 17.00	\$ 15.30
AC ADAPTERS AND CHARGERS					
	7875A002 #	Compact Power Adapter CA-PS700	PowerShot G1 X Mark II, G1 X, G16, G15, S80, SX1 IS, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, S5 IS, S3 IS, S2 IS. (See EOS accessories for additional compatibility)	\$ 65.00	\$ 58.50
	0992C001 #	Compact Power Adapter CA-DC30	PowerShot G1 X Mark III, G5 X, G7 X Mark II*, G9 X Mark II*, G9 X*, SX740 HS*, SX730 HS*, SX720 HS*, N2**, N** * USB Cable IFC-600PCU is necessary. ** USB Cable IFC-400PCU is necessary.	\$ 40.00	\$ 36.00
	7640A001 #	AC Adapter Kit ACK-800	PowerShot SX160 IS, SX150 IS, SX130 IS, SX120 IS, SX110 IS, A2100 IS, A2000 IS, A1300, A1200, A1100 IS, A1000 IS, A1400, A810, A800, A720 IS, A710 IS, A700, A590 IS, A570 IS, A580, A560, A550, A540, A530, A520, A510, A495, A490, A480, A470, A460, A430, A410, A400, A310, A300, A200, A100, E1 (Includes: Compact Power Adapter CA-PS800, Power Cable)	\$ 49.00	\$ 44.10
	9838B001	AC Adapter KIT ACK-DC110	PowerShot G5 X, G7 X, G9 X Mark II, G9 X, SX740 HS, SX730 HS	\$ 70.00	\$ 63.00
	9535B001 #	AC Adapter Kit ACK-DC100	PowerShot G1 X Mark II, N100	\$ 70.00	\$ 63.00
	6216B001 #	AC Adapter Kit ACK-DC90	PowerShot SX420 IS, SX410 IS, SX400 IS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 320 HS, ELPH 190 IS, ELPH 170 IS, ELPH 180, ELPH 160, ELPH 150 IS, ELPH 140 IS, ELPH 135, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, A4000 IS, A2600, A2500, A3400 IS, A2400 IS, A2300	\$ 70.00	\$ 63.00
	5667B001 #	AC Adapter Kit ACK-DC80	PowerShot G1 X, G3 X, G16, G15, SX60 HS, SX50 HS, SX40 HS	\$ 70.00	\$ 63.00
	4726B001 #	AC Adapter Kit ACK-DC70	PowerShot N2, N, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, SD4500 IS	\$ 70.00	\$ 63.00
	4266B001 #	AC Adapter Kit ACK-DC60	PowerShot TX1, SD960 IS, SD940 IS, SD780 IS, ELPH 330 HS, ELPH 310 HS, ELPH 300 HS, SD1400 IS, SD770 IS, SD1100, SD1000, SD750, SD630, SD600, SD450, SD400, SD430 Wireless, SD300, SD200, SD40, SD30, A3300 IS, A3100 IS, A3000 IS, A2200	\$ 70.00	\$ 63.00
	2610B001 #	AC Adapter Kit ACK-DC40	PowerShot S120, S95, S90, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX710 HS, SX700 HS, SX280 HS, SX260 HS, SX610 HS, SX600 HS, SX170 IS, D30, D20, D10, ELPH 500 HS, SD4000 IS, SD3500 IS, SD980 IS, SD1300 IS, SD1200 IS, SD770 IS	\$ 70.00	\$ 63.00
	1137B001 #	AC Adapter Kit ACK-DC30	PowerShot S110, S100, SX230 HS, SX210 IS, SX200 IS, SD990 IS, SD950 IS, SD900, SD970 IS, SD890 IS, SD790 IS, SD880 IS, SD870 IS, SD850 IS, SD800 IS, SD700 IS	\$ 70.00	\$ 63.00
	5190B001 #	DC Coupler DR-DC10	PowerShot SX160 IS, SX150 IS, A1400, A1300, A810, A800 (A1400, A1300, A810, A800 used with ACK-800)	\$ 22.00	\$ 19.80
	9840B001 #	Battery Charger CB-2LH	PowerShot G1 X Mark III, G5 X, G7 X Mark II, G7 X, G9 X Mark II, G9 X, SX740 HS, SX730 HS, SX720 HS, SX620 HS	\$ 50.00	\$ 45.00
	9513B001 #	Battery Charger CB-2LG	PowerShot G1 X Mark II, N100	\$ 50.00	\$ 45.00
	8419B001 #	Battery Charger CB-2LF	PowerShot SX420 IS, SX410 IS, SX400 IS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 320 HS, ELPH 190 IS, ELPH 170 IS, ELPH 180, ELPH 160, ELPH 150 IS, ELPH 140 IS, ELPH 135, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, A4000 IS, A2600, A2500, A3400 IS, A2400 IS, A2300	\$ 50.00	\$ 45.00
	5669B001 #	Battery Charger CB-2LC	PowerShot G1 X, G3 X, G16, G15, SX60 HS, SX50 HS, SX40 HS	\$ 50.00	\$ 45.00
	4723B001 #	Battery Charger CB-2LB	PowerShot N2, N, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, SD4500 IS	\$ 50.00	\$ 45.00
	3154B001 #	Battery Charger CB-2LZ	PowerShot G12, G11, G10, SX30 IS	\$ 50.00	\$ 45.00
	2608B001 #	Battery Charger CB-2LY	PowerShot S120, S95, S90, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX710 HS, SX700 HS, SX280 HS, SX260 HS, SX610 HS, SX600 HS, SX170 IS, D30, D20, D10, ELPH 500 HS, SD4000 IS, SD3500 IS, SD980 IS, SD1300 IS, SD1200 IS, SD770 IS	\$ 50.00	\$ 45.00
	1133B001 #	Battery Charger CB-2LX	PowerShot S110, S100, SX230 HS, SX210 IS, SX200 IS, SD990 IS, SD950 IS, SD900, SD970 IS, SD890 IS, SD790 IS, SD880 IS, SD870 IS, SD850 IS, SD800 IS, SD700 IS	\$ 50.00	\$ 45.00
	0763B001 #	Battery Charger CB-2LW	PowerShot G9, G7, S80, S70, S60, S50, S45, S40, S30 (Replacement of CB-2LT)	\$ 55.00	\$ 49.50
	9764A001 #	Battery Charger CB-2LV	PowerShot TX1, SD960 IS, SD940 IS, SD780 IS, ELPH 330 HS, ELPH 310 HS, ELPH 300 HS, SD1400 IS, ELPH 100 HS, SD1100 IS, SD1000, SD750, SD630, SD600, SD450, SD400, SD430 Wireless, SD300, SD200, SD40, SD30	\$ 50.00	\$ 45.00
CABLES					
	1015C001 #	USB Cable IFC-600PCU	PowerShot G1 X Mark III, G5 X, G7 X Mark II, G9 X Mark II, G9 X, SX740 HS, SX730 HS, SX720 HS, SX620 HS	\$ 16.00	\$ 14.40
	9370A001 #	USB Cable IFC-400PCU	All PowerShot cameras except Pro90 IS, Pro70, G1 X Mark III, G2, G1, SD10, S230, S200, S110, S100**, S20, S10, A50, 600, A5 Zoom, A5 (See EOS accessories for additional compatibility)	\$ 16.00	\$ 14.40
	2384B001 #	Mini-HDMI Cable HTC-100	PowerShot G1 X, G3 X, G16, G15, G12, G11, S120, S110, S100, S95, S90, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX20 IS, SX10 IS, SX1 IS, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX280 HS, SX260 HS, SX230 IS, SX210 IS, SX200 IS, SX160 IS, D30, D20, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, ELPH 500 HS, ELPH 330 HS, ELPH 320 HS, SD4500 IS, SD4000 IS, SD3500 IS, ELPH 310 HS, ELPH 300 HS, SD1400 IS, ELPH 110 HS, ELPH 100 HS, SD970 IS, SD980 IS, SD960 IS, SD940 IS, SD780 IS	\$ 80.00	\$ 72.00

	4076B001 #	Stereo AV Cable AVC-DC400ST	PowerShot G1 X Mark II, G1 X, G7 X, G16, G15, G12, S120, S110, S100, S95, SX60 HS, SX50 HS, SX40 HS, SX30 IS, SX540 HS, SX530 HS, SX520 HS, SX510 HS, SX500 IS, SX710 HS, SX700 HS, SX280 HS, SX260 HS, SX230 HS, SX210 IS, SX170 IS, SX160 IS, SX150 IS, SX130 IS, N100, ELPH 530 HS, ELPH 520 HS, ELPH 510 HS, ELPH 500 HS, ELPH 330 HS, ELPH 320 HS, ELPH 310 HS, ELPH 300 HS, SD4500 IS, SD4000 IS	\$ 25.00	\$ 22.50
	2563B001 #	AV Cable AVC-DC400	PowerShot G11, S90, SX610 HS, SX600 HS, SX420 IS, SX410 IS, SX400 IS, SX200 IS, SX120 IS, SX110 IS, D30, D20, D10, SD4500 IS, SD4000 IS, SD3500 IS, SD990 IS, SD970 IS, SD890 IS, SD880 IS, SD790 IS, SD980 IS, SD960 IS, SD940 IS, SD780 IS, SD1400 IS, ELPH 360 HS, ELPH 350 HS, ELPH 340 HS, ELPH 190 IS, ELPH 170 IS, ELPH 180, ELPH 160, ELPH 150 IS, ELPH 140 IS, ELPH 135, ELPH 130 IS, ELPH 115 IS, ELPH 110 HS, ELPH 100 HS, SD1200 IS, SD770 IS, A4000 IS, A3400 IS, A3300 IS, A3100 IS, A3000 IS, A2600, A2500, A2400 IS, A2300, A2100 IS, A2000 IS, A1400, A1300, A1100 IS, A1000 IS, A810, E1	\$ 16.00	\$ 14.40
	9371A001 #	AV Cable AVC-DC300	PowerShot Pro1, Pro90 IS, G10, G9, G7, G6, G5, G3, G2, G1, S80, S70, S60, S50, S45, S40, S30, SX160 IS, SX150 IS, SX130 IS, SX120 IS, SX110 IS, SD950 IS, SD900, SD870 IS, SD850 IS, SD800 IS, SD700 IS, SD1100 IS, SD1000, SD750, SD630, SD600, SD550, SD500, SD110, SD100, SD450, SD400, SD430 Wireless, SD300, SD200, SD40, SD30, SD20, SD10, S500, S410, S400, S330, S300, S230, S200, S110, S100**, A2200, A2100 IS, A2000 IS, A1100 IS, A1000 IS, A1200, A720 IS, A710 IS, A700, A650 IS, A640, A630, A620, A610, A590, IS, A570 IS, A580, A560, A550, A540, A520, A510, A530, A800, A495, A 490, A480, A470, A460, A430, A410, A400, A85, A75, A70, A60, A40	\$ 16.00	\$ 14.40
	3067A002 #	Stereo Video Cable STV-250N	PowerShot SX150 IS, SX20 IS, SX10 IS, SX1 IS, S5 IS, S3 IS, S2 IS, TX1 (See EOS accessories for additional compatibility)	\$ 22.00	\$ 19.80
	1719B001 #	Component Cable CTC-100	PowerShot TX1	\$ 50.00	\$ 45.00
	2477A002 #	Timer Remote Control TC-80N3	PowerShot G1 X Mark III (See EOS accessories for additional compatibility)	\$ 210.00	\$ 189.00
	1157C001 #	Remote Controller Adapter RA-E3	PowerShot G1 X Mark III (See EOS accessories for additional compatibility)	\$ 45.00	\$ 40.50
CONTROLLER					
	2469A002 #	Remote Switch RS-60E3	PowerShot G1 X Mark III, G1 X Mark II, G1 X, G3 X, G5 X, G16, G15, G12, G10, G11, SX60 HS, SX50 HS	\$ 30.00	\$ 27.00